

## ENGINEERING CHANGE NOTICE

Date: 03.04.28				ECN #: 524
Project No.: D350-600	Created By: <i>[initials]</i>	Checked By: <i>[initials]</i>		
Project Name: AS 350/355 SPACERS	Approved By: <i>[initials]</i> (proj. manager)	Approved By: <i>[initials]</i> (management if req'd)	N/A	
Description of Change: <i>RELEASE: D3187 Rev. A D0600-146 Rev. A D3188 Rev. A D0600-145 Rev. A D3186 Rev. A D0600-143 Rev. A D0600-142 Rev. A D0600-141 Rev. A</i>				
Notification/Acceptance	Affected	Authorization		
QA	✓	P302-501		
Production	✓			
Planning	✓			
Marketing	N/A			
Engineering Actions	Yes	No	Responsible	To happen by
Update Blue File		✓		
Update Pink File		✓		
Update D-Part Master Binder	✓		KJ	03.04.29
Update Grey Project Binder		✓		03.04.29 <i>[initials]</i>
Update DEO Binder		✓		
Update Master Document List		✓		
Update Drawing Approval Record	✓		DS	03.04.28
Update Change Record Form	✓		DS	03.04.29
Move Electronic File	✓		DS	03.04.29
Notify TCA of Change	✓		DS	03.04.28
Notify FAA of Change		✓		03.04.28
Update QSI 021		✓		
Update QSI 036		✓		
Scan Documents		✓		
Update MIS Database	✓		KJ	03.04.29
Update Access Database	✓		KJ	03.04.29
Verification ARC	✓		DS / KJ	03.04.29
Notes:				
<ul style="list-style-type: none"> <li>- CREATE IPP's/BOMs FOR D350-600-141/-142 + D355-600-143 + D350-600-145/-146</li> <li>- D350-600-141/-142/-145/-146 + D355-600-143 ALL AT CHG 001</li> <li>- SEND CONTROLLED COPIES OF D3188 Rev. A + D3186 Rev. A TO DELASTEK. (Inventor done)</li> <li>- CREATE TEMPLATES FOR MAKING FLOORS + INSTALLING FLOOR INSERTS.</li> <li>- CREATE NEW IPP's</li> </ul>				